

Product Description: Treatex Hardwax Oil

Natural eco-friendly surface treatment for internal timber surfaces, for the coating of all internal timber, particularly floors, as well as porous surfaces such as stone tiles.

- **Durable** clear hardwax finish that is easily maintained, is water repellent and dirt resistant
- **With proper application** will not discolour, crack, flake or peel.
- **Safe** for use on children's' toys contains no pollutants and minimal solvents
- **Microporous**, allows timber to breathe and move seasonally.
- **Enhances** natural grain and timber colour, tends to be non-yellowing and will not edge bond when applied correctly.
- Available in four sheen levels, Matte, Luster, Satin, and Gloss.

Recommended Tools:

120 grit screen, 220 grit screen, Stirring stick, paint tray, brush or 5 or 6mm mohair roller.

Clean tools: with WHITTLE WAXES SPECIAL-THINNER.

Container sizes: 500ml, 1L, 2.5L, 5L

Coverage Rate:

You should achieve with the 1st coat 15-20m²/L and with the 2nd coat ~25m²/L.

Coats needed: 2 coat system

Sheen Levels: Matte, Luster, Satin and Gloss

Container sizes: 500ml, 1L, 2.5L, 5L,

Drying time: Allow to dry for at least 12 hrs – Warmth and ventilation will speed up the drying process. Cold and humidity may slow down the process. 8-10 days to cure fully, Keep the floor dry during this time

Storage: Indefinite in sealed container.

Floor Preparation:

1. The floor needs to have been well sanded to a 120 grit Screen.
2. Vacuum the surface thoroughly to remove all dirt and dust.
3. Before applying Treatex® to the whole floor, please test on a small area.
4. Plan how you are going to coat the floor in an efficient manner.

Application:

5. Stir tin thoroughly and pour required amount to complete the coat into paint tray.
6. Apply Treatex® cutting in from skirtings' using the brush, do not get too far ahead.
7. Load the 5 or 6 mm mohair roller from the paint tray and apply an even coat of Treatex® to the floor.
8. Work the length of the boards covering an area approximately 750mm in width.
9. Work efficiently and aim to achieve an even coat.
10. Allow to dry overnight, airflow will speed up drying time.
11. Key in with a 220 grit sandpaper, and repeat the process.
12. Two coats are all that is required
13. Do not leave waste sanding powder in vacuum unit! Risk of spontaneous combustion.

Ingredients: Oil and Wax combinations on a base of natural, sustainable raw materials including Linseed oil, sunflower oil, Jojoba oil, Beeswax, carnauba wax and candalilla wax.



International GHS Safety Notes: P210 Keep away from heat, hot surfaces, sparks, open flame and other ignition sources. No smoking. P261 Avoid breathing dust/fume/gas/mist/vapours/spray. P280 Wear protective gloves/protective clothing/eye protection/face protection. P30 +P340 IF INHALED: Remove person to fresh air and keep comfortable for breathing. P309+P315 IF exposed or if you feel unwell: Get immediate medical advice/attention. P403+P233 Store in a well-ventilated place. Keep container tightly closed. H226 Flammable liquid and vapour. H336 May cause drowsiness or dizziness.

Disclaimer: Our technical advice in written form is given in good faith and on the basis of experiments, but it is only non-binding advice and does not release you from the obligation to test the products supplied by us as to their suitability for the particular purpose. Application, use and processing of the products outside our direct control are entirely your responsibility. Naturally we guarantee consistent quality of our products corresponding to the original sample. With release of new product information the previous information loses validity.